

SNX

Setting Minimum/Maximum for ITF with the CCD Scanner

Your CCD scanner is set to read a default of 10 characters for Interleaved Two of Five (ITF) codes. To set the unit to read a **minimum of 4** and a **maximum of 48**, scan the following codes:

Enter Group 7



Interleaved Two of Five (ITF)



Enable Code (default setting)



Use a fixed length by the first 3 reads (default setting)



Do not calculate check digit (default setting)



Do not suppress sending of first or last digit (default setting)



Set minimum



Four



Exit Minimum



Enter Maximum



Four



Eight



Exit Maximum



Exit Program



Sample ITF 2 of 5 Code (4 digit)



1234

This procedure sets the minimum to 4 characters (lower limit) and the maximum to 48 characters (upper limit).

Changes stay in effect until another setting has been entered in programming.

If this document does not resolve your problem, please contact SNX technical support at:

PLEASE NOTE: Technical support is not available from our toll free number. All registered users requiring technical support must call (718) 369-2944.

SNX

Technical Support Hours: Mon-Fri 10am-6pm EST

692 10th Street

Brooklyn, NY 11215

Phone: (718) 369-2944

Fax: (718) 768-3997

World Wide Web:

www.snx.com

Email:

support@snx.com